

HONDA CIVIC HATCHBACK 5 DOOR - 2017 - 2022

OUR REF: H0702

PACKAGING REQUIREMENTS.

☐ BOOT LINER

- **2x 350 mm** 20mm wide self-adhesive loop fastener
- **31 x Ref: 113** (Frequent use fastener tabs)
- **1x tabs** self-adhesive loop fastener

☐ TAILGATE COVER

- **22x tabs** self-adhesive loop fastener



Rear Split bootliner with seat flap preparation



REF:113



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.



**The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*

Please note the following photos are non-specific to your vehicle

STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced

STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image A)
-



STEP 3. FITTING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and the seat panel. (image B)
- Fasten the hook fastener welded onto the top edge of the boot liner sides directly onto the carpet along the top edge of the carpet on the back of the rear seats. (image C)
- We have provided a set of Ref:113 tabs should you also wish to use these improve the fitting of the boot liner. The tab fastens to the carpet, and then the boot liner hook weld attaches to the tab.

Leave the tab attached to the carpet when folding the rear seats or removing the boot liner.



REAR PLUS VERSIONS

You **MUST** unfasten the hook fasteners before you recline the rear seat uppers. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo)

STEP 4. FITTING THE SIDES & BACK

- Fasten the hook fastener welded onto the top edge of the boot liner sides directly onto the carpet along the top edge of the carpeted boot sides. (image D)
- You can also use the Ref:113 tabs here should you wish to. (image E)
- Attach the 2x 350 mm 20mm wide self-adhesive loop fastener along the tailgate edge of the boot liner starting from the lock in the middle going along the plastic panel (image F).
- Snip the self-adhesive fastener strips in the corners to ease around the bend. Fasten the boot liner to it using the hook fastener welded onto it. (image F)
- Stick 1 self-adhesive fastener tab on the center inside of the back panel in line with the hook fastener welded onto the back panel of the boot liner. (arrow - Image F)



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests that can be lowered.
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)



STEP 5B. TAILGATE COVER



Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The “Floor extension” offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.(image 6)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors



The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will “fluff” up – we have the alternative “Frequent Use Fitting Kit” (image 7+8)

The Frequent Use Kit is also available to buy from “on-line”

