

Mercedes-Benz A-Class Hatchback- 2018 on

our ref: H0720

Packaging requirements:

BOOT LINER

- **2 x 360mm** 30mm wide self-adhesive loop fastener
- **SH2 ONLY:**
1 x tab self-adhesive loop fastener

TAILGATE COVER

- **20 x tabs** self-adhesive loop fastener



SHI: Rear split, prepared for seat flap and bumper flap



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Put the headrests in its highest position.



STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image B)



STEP 3. FITTING THE FRONT

- - PLUS / SPLIT VERSION ONLY - fasten the hook & loop fasteners between the side panels and the seat panel. (image C)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (image D). Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Then fasten the hook fastener strips sewn on the top of the front part of the boot liner directly to the top part of the carpeted back of the seats. (white arrows - image D)



REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. ('Please refer to REAR PLUS / SPLIT options on website to see detailed photo')

STEP 4. FITTING THE SIDES

- Fasten the hook fastener sewn onto the top edge and tailgate end of the boot liner sides directly onto the carpet along the top edge and back edge of the carpeted boot sides and back (image E)



IMAGE E

STEP 5. FITTING THE BACK



- Stick the **360mm self-adhesive loop fastener** onto the plastic panel located on both sides of the lock at the tailgate end of the boot. Fasten the boot liner to it using the hook fastener sewn on the reverse face. (green - Image F)
- **SH2 ONLY:** Stick 1 self-adhesive fastener tab on the center inside of the back panel in line with the hook fastener welded onto the back panel of the boot liner. (arrow - Image F)



IMAGE F

OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP/TAILORED SEAT FLAP

- The Seat Flap/Tailored Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (image 1 & 2)
- Lower the headrests
- Attach the Seat Flap/ Tailored Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (image 1 & 2)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 1 & 2)
- If you choose the Tailored Seat Flap and a Rear Plus/Split we include an additional Seat Flap that is **only** to be used in conjunction with the **Rear Plus/Split**.
- With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests. (image 3)



STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors



The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit" (image 7+8)

The Frequent Use Kit is available to buy from our "on-line" Factory Shop – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

