

## Volvo V60 - 2018 Onwards

our ref: H0776

### PACKAGING REQUIREMENTS:

BOOT LINER

- 2 x tabs self-adhesive loop fastener

TAILGATE COVER

- 24 x tabs self-adhesive loop fastener



Split boot liner with Ski flap prepped for a seat flap, bumper flap & bootliner extension.



### VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

*\*The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



## STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.

## STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image A)
- Attach 1 self adhesive tab onto the plastic section of each side of the base near the tailgate opening in line with the hook fastener sewn onto the boot liner base. (yellow highlight - image B)



## STEP 3. FITTING THE FRONT (ELASTIC)

- - PLUS / SPLIT VERSION ONLY - fasten the hook & loop fasteners between the side panels and seat panel. (image C)
- Loop the elastic fastener straps around both headrest posts. (image D). Make sure to hold the front part of the base in position as not to pull the boot liner too far up.
- Fasten the middle of the front panel directly to the carpeted area of the rear seats using the hook fastener welded onto the boot liner.



## REAR PLUS VERSIONS

- You MUST unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)

## STEP 4. FITTING THE SIDES

- Push the boot liner behind the nearside net. The net will remain exposed. (image E)
- Fasten the hook fastener sewn and welded onto the top and rear edge of the boot liner sides directly onto the carpet along the top edge of the carpeted boot sides. (image E)



## OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

### STEP 5A. SEAT FLAP (+TAILORED)

- The **Tailored** Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc. (image 1)
- Lower the headrests
- Attach the Tailored Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats.
- The additional Seat Flap is designed **only** to be used in conjunction with the **Rear Plus/Split**. With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests. (image 2)



### STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 3)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



### STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



## OPTIONAL EXTRAS PAGE 2

Please note the following photos are non-specific to your vehicle

### STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6 & 7)

- The Floor extension is designed to attach to a Rear Plus/Split version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It will offer no full protection to the rear doors
- Attach the floor extension to the main boot liner (Image 6)
- Fasten the two ties in the corner together (Orange arrows - Image 7)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 7)

The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

### STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit" (image 8+9)

The Frequent Use Kit is available to buy from our "on-line" Accessories Page – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

