

## Kia XCeed - 2019 Onwards

our ref: H0788

### PACKAGING REQUIREMENTS:

#### BOOT LINER

- **2 x 360 mm** 30mm wide self-adhesive loop fastener
- **21 x REF:113** Frequent Use tabs
- **1 x tabs** self-adhesive loop fastener

#### TAILGATE COVER

- **20 x tabs** self-adhesive loop fastener



Ref:113



**Left:** FRSD Rear Plus with Seat Split boot liner prepped for a bumper flap & front D-ring access

**Right:** FLOW Rear Plus boot liner prepped for seat flap, bumper flap, boot liner extension & front D-ring access



### VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

*\*The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



Please note not all of the photographs are specific to your vehicle

## STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Set the floor level to fit the specification of your order.
- Put the headrests in their highest position. **(image A)**



## STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. **(image B)**



## STEP 3. FITTING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and the seat panel. **(image C)**
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. **(image D)**. Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.
- Lower the headrests.



## REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. *(Please refer to REAR PLUS / SPLIT options on website to see detailed photo)*

## STEP 4. FITTING THE SIDES

### FRSD & FOUT version boot liners

- Pass the 2 straps on the left side through the corresponding slots in the boot liner. (image E)

### REF:113 FREQUENT USE TABS

Normally the hook fastener tabs that are welded / sewn on to the boot liner side panel would attach directly to the boot carpet. However for a more secure fit, we have included 21 frequent use tabs that have hook fastener on one side and loop on the other. These are placed between the carpeted boot sides and the boot liner. We recommend you use these on the sides of the boot

- Fasten the hook fastener sewn & welded onto the top edge of the boot liner sides directly onto the carpet along the top edge of the carpeted boot sides. (image F)
- Starting at the tailgate end of the sides : carefully peel back the boot liner to expose the carpet and fix one ref:113 in-line with where the hook fastener had been attached. (image G)
- Re-fasten the Boot liner side panel to the ref:113 tabs.(image F & H)

**FRSD VERSION** ( image E,F&G)

**FOUT VERSION** ( image H)



## STEP 5. FITTING THE BACK

- Stick 1 x 360 mm 30mm wide self-adhesive loop fastener onto the plastic panel located at the tailgate end of the boot side and in line with the hook fastener welded onto the reverse side of the boot liner. Snip the self-adhesive fastener strips in the corners to ease around the bend. (image I)  
Repeat on opposite side.
- **FLOW ONLY** - Stick 1 self-adhesive fastener tab on the center inside of the back panel in line with the hook fastener welded onto the back panel of the boot liner. (arrow - Image I)




## OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

### STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

### STEP 5B. TAILGATE COVER

-  Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

### STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



## OPTIONAL EXTRAS PAGE 2

Please note the following photos are non-specific to your vehicle

### STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6 & 7)

- The Floor extension is designed to attach to a Rear Plus/Split version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It will offer no full protection to the rear doors
- Attach the floor extension to the main boot liner (Image 6)
- Fasten the two ties in the corner together (Orange arrows - Image 7)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 7)

**The Seat Flap 5A, the Bumper Flap 5C & the Bootliner Extension 5D cannot be added at a later date.**

