

Ford Tourneo Custom L2 H1 - 2012 to 2018

Our ref: H0901

FITTING KIT CONTENTS:

BOOT LINER

- **A 1 x 1490mm** 50mm wide self-adhesive loop fastener
- **B 1 x 2200mm** 30mm wide self-adhesive loop fastener
- **C 1 x 1640mm** 30mm wide self-adhesive loop fastener
- **1 x tab** self-adhesive loop fastener

TAILGATE COVER

- **D 1 x 2700mm** 30mm wide self-adhesive loop fastener
- **E 1 x 900mm** 30mm wide self-adhesive loop fastener
- **5 x tabs** self-adhesive loop fastener



Rear Plus with Seat Split boot liner prepped for a seat flap and bumper flap.



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*



STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Put the headrests in their highest position. (Image A)
- Cut the included loop fasteners to the following sizes:
 - A 680mm, 450mm, 230mm, 130mm
 - B 900mm, 850mm, 450mm
 - C 700mm, 340mm, 370mm, 230mm



TAILGATE COVER ONLY:

- D 2x 850mm, 2x 500mm
- E 600mm, 300mm

STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the underside attach directly to the carpet. (Image B)



STEP 3. FITTING THE FRONT

- **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image C)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image D). Make sure to hold the front part of the base in position to avoid pulling the boot liner too far up. Repeat the procedure with the left and right headrests.




REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper part of the rear seats. (Please refer to **REAR PLUS / SPLIT options on website to see detailed photo.**)



STEP 4. FITTING THE SIDES

- On the right side of the boot attach the following loop fasteners in line with the hook fasteners sewn & welded on the reverse side of the boot liner as highlighted on **Image E**.
 - Green 680mm loop fastener
 - Orange 130mm loop fastener
 - Pink 340mm loop fastener (30mm wide)
- On the left side of the boot attach the following loop fasteners as highlighted on **Image F**.
 - Green 450mm loop fastener (50mm wide)
 - Orange 230mm loop fastener
 - Pink 370mm loop fastener
 - Yellow loop fastener tab
- Fasten the hook fastener sewn onto the top and back edge on both sides of the boot liner directly onto the previously attached loop fasteners.



STEP 5. FITTING THE BACK

- Stick the following fasteners to the tailgate edge of the boot area. (**Image G**).
 - Green 850mm loop fastener
 - Orange 900mm loop fastener
 - Pink 450mm loop fastener
 - Yellow 230mm loop fastener
 - Blue 700mm loop fastener
- Snip the self-adhesive fastener strips at the corners to ease around the curve. Attach the boot liner to it using the hook fastener on the liner.




OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle.

STEP 5A. SEAT FLAP

The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.

- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (Image 1)
- The flap is then placed over the rear head rests and down the front of the passenger seats. (Image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward.



STEP 5B. TAILGATE COVER

- Stick the following loop fasteners in line with the hook fasteners on the reverse side of the tailgate cover as highlighted on Image 3.
 - Green 850mm loop fasteners
 - Orange 500mm loop fasteners
 - Blue 600mmmm loop fastener
 - Pink 300mmmm loop fastener
 - Yellow 5x loop fastener tabs
- Attach the cover to the plastic trim previously fitted loop fasteners



STEP 5C. BUMPER FLAP

- Fit the boot liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the boot liner. (Image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



Please Note: the Seat Flap, the Bumper Flap cannot be added at a later date.

OPTIONAL EXTRAS PAGE 2

Please note: not all of the photographs are specific to your vehicle.

STEP 6E. FREQUENT USE KIT

- If you frequently remove/install your boot liner from/to your vehicle, please note that the carpet will “fluff” up – we offer an alternative Frequent Use Fitting Kit. These tabs are placed between the boot liner and the boot carpet.(Image 9 & 10)

The Frequent Use Kit is an accessory available to purchase from our on-line store.



Image 9



Image 10