THE Hatchbag COMPANY

FITTING INSTRUCTIONS

hatchbag.co.uk

MINI CLUBMAN 2007on

Our ref: H0453

Please note; This photo shows the "LOWERED" Floor version

PACKING REQUIREMENTS

☐ BOOT LINER

"RAISED" + "LOW FLOOR" BOOT LINER
Minimum of 9 self-adhesive loop fastener tabs

☐ REAR DOOR COVER
Minimum of 21 self-adhesive loop fastener tabs

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the boot liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE**:** the adhesive takes 24hrs to reach full adhesion, do not disturb during.

PREPARATION

- Remove the load cover. It may be replaced later
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.
- Ensure you have removed or positioned the False Floor to suit the boot liner you have purchased.

These photos are non-specific to your vehicle

FITTING

BASE

- Position the base snugly into place. Start at the tailgate end. The hook fastener welds will attach directly to the carpet.
- Use the self-adhesive loop fastener to attach the back panel to the tailgate plate.
- Attach the self-adhesive loop fastener tabs to the hook fastener on the liner. Peel off protective backing, reposition panel and apply **FIRM** pressure at tab location points to ensure maximum adhesion to structure.

FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener welded to the reverse face of the liner will attach directly to the carpet on the back of the seats.

REAR PLUS VERSIONS

- YOU MUST UNFASTEN THE HOOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo's)

SIDES

- Carefully position the side panels snugly into place.
- The hooK fastener will attach directly to the carpet.

OPTIONAL EXTRAS

FREQUENT USE KIT

If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet on the floor and seat back will "fluff" up – we have an alternative "Frequent Use Fitting Kit" The Frequent Use Kit is available to buy from our "on-line" Factory Shop – simply add it to your order from the Factory Shop.

REAR SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

TAILGATE COVER

- Use the self-adhesive loop fastener tabs to attach the covers to the plastic trim.