

FIAT 500X 2015ON

OUR REF: H0651-FRSD /FLOW / FNO & HR2 / HR3

PACKAGING REQUIREMENTS.

☐ BOOTLINER

- **13x tabs** self-adhesive loop fastener

- 2 x REF:113

(ONLY FOR HR2)



REF:113



Rear Plus boot liner
FLOW-HR2

Rear Split boot liner
prepped for seat flap,
bumper flap

☐ TAILGATE COVER

- **18 x tabs** self-adhesive loop fastener



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fasteners sticks to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a **separate** clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if it doesn't stick)
3. Attach the fasteners and let them fully adhere over the next 24 hours for the best bond.



**The fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*

STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Ensure if you have a variable floor that your floor is set to the level to suit your order. Refer to the VI (Vehicle identification sheet)




STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image A)



STEP 3. FITTING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and seat panel. (image B)
- Starting with the centre headrest for HR3 version or an outer headrest for HR2 version, loop the hook & loop fastener straps around both headrest posts. (image C). Make sure to hold the front part of the base in position so as not to pull the Hatchbag too far up. Repeat the procedure with the other headrests.
- - **HR2 VERSION ONLY** - Establish where the 2 liner fasteners have been designed to attach to the carpet section of the seat back. Attach 113 tabs to the carpet first, and then the liner fasteners will attach to these. (image D).
- PLEASE NOTE; To recline the seat /remove the liner, peel it away from the 113 tabs leaving them in situ. This will reduce the carpet from fluffing up.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)

STEP 4. FITTING THE SIDES

- Position the front of the side snugly into position. The hook fasteners welded to the reverse face of the liner will attach directly to the carpet.
(LOW FLOOR image E / RAISED FLOOR image F)
- Repeat on opposite side.



FITTING THE BACK



Stick the self-adhesive tabs onto the plastic panel located at the tailgate end of the boot side and in line with the hook fasteners welded onto the reverse side of the boot liner. (image G) Repeat on opposite side.

- Stick 1 self-adhesive fastener tab on the center inside of the back panel in line with the hook fastener welded onto the back panel of the boot liner. (arrow - Image G)



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the bootliner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 3)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



STEP 5B. BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



STEP 5C. TAILGATE COVER (image 6)

- Line up the tailgate cover with the tailgate and clean only the areas where the self-adhesive fastener tabs will be stuck to the plastic.
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.
- The remaining fasteners will attach directly to the carpet.



STEP 5D. FLOOR EXTENSION

The “Floor extension” offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 7)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm.
- It will offer no protection to the rear doors



REF: I 13 TABS -FREQUENT USE KIT

- If you frequently remove/fit your bootliner from/to your vehicle please note that the carpet will “fluff” up – you can purchase a “Frequent Use Fitting Kit”
- To Use : As you fit the bootliner, establish where the liners loop fastener has been designed to attach to the carpet. Attach 113 tabs to the carpet first, and then the liner fasteners will attach to these.
- PLEASE NOTE; To remove the liner, peel it away from the 113 tabs leaving them in situ. This will reduce the carpet from fluffing up.



The Seat Flap 5A, The Bumper Flap 5B & The Floor Extension 5D cannot be added at a late date