

Land Rover Freelander 2 - 2006 to 2014

Our ref: H0428

FITTING KIT CONTENTS:

BOOT LINER

- 2 x 370mm 25mm wide self-adhesive loop fastener
- 14 x tabs self-adhesive loop fastener
- 6 base hook /loop fastener tabs

TAILGATE COVER

- 21 x tabs self-adhesive loop fastener



Rear Plus with Seat Split boot liner prepped for a seat flap.



base hook /loop fastener tabs



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.


**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*



Please note: not all of the photographs are specific to your vehicle.

STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Put the headrests in their highest position. (Image A)



STEP 2. FITTING BASE

Location A in Image B

- Attach the ties to the adjacent luggage tie down hooks

Location B in Image B

- Familiarize yourself with the position of the 6 hook fastener welds on the reverse side of the liner at the tailgate end.
- Lift up the false floor. Attach the 6 fastener ref: base hook /loop fastener tabs to the inside plastic vertical face using the 6 self-adhesive loop fastener tabs (Image C)
- The tabs will protrude out of the floor panel when its replaced allowing the liner to be fastened to them (Image D)
- Fasten the base to these tabs



PLEASE NOTE: The Offside well in your vehicle may be deeper than the liner. This is due to your vehicle spec. As we have made the liner to fit many options, you may prefer to place a piece of foam / rag under the liner first, to fill this void.

STEP 3. FITTING THE FRONT

- **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image E)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image F). Make sure to hold the front part of the base in position to avoid pulling the boot liner too far up. Repeat the procedure with the left and right headrests.
- Pass the elastic loops around and under the plastic mouldings that house the rear seat unlock buttons. (Image G).



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper part of the rear seats. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo.)

STEP 4. FITTING THE SIDES

- On both sides of the boot stick the following loop fasteners in line with the hook fasteners sewn & welded on the reverse side of the boot liner as highlighted on **Image H**
 - Green 370 mm loop fastener
 - Yellow loop fastener tabs
- Fasten the hook fastener sewn onto the top and back edge on both sides of the boot liner directly onto the previously attached loop fasteners.

The black taped edges on the tailgate end of the sides are designed to sit under the rubber door seal (Image H & I)
- The ties attach to the exposed rear seat locking catches just behind the rear seats.



OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle.

STEP 5A. SEAT FLAP

The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.

- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (Image 1)
- The flap is then placed over the rear head rests and down the front of the passenger seats. (Image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (Image 3)



STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (Image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5C. BUMPER FLAP

- Fit the boot liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the boot liner. (Image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS PAGE 2

Please note: not all of the photographs are specific to your vehicle.

STEP 5D. BOOT LINER EXTENSION

The Boot liner extension provides superior protection for the rear seats when purchased with a REAR PLUS option.

- The Boot liner Extension is designed to attach to a Rear Plus/Split version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- It offers no protection to the rear doors
- Attach the Boot liner Extension to the main boot liner (Image 6)

Please note: the Seat Flap, Bumper Flap and Boot liner Extension cannot be added at a later date

