

FITTING INSTRUCTIONS

hatchbag.co.uk

MAZDA 6 2012 on

Our ref: H0587

Packing requirements



BOOTLINER

Minimum of 14 x REF 113 (double sided fastener patches)

Minimum of 12 self-adhesive loop fastener tabs

REF: 113

REAR DOOR COVER

Minimum of 16 self-adhesive loop fastener tabs



Photo: Rear Plus WITH Seat Split version Boot Liner prepared for a Bumper flap and Seat Flap

PREPARATION

• Remove the load cover. It may be replaced later. The boot liner accommodates the load cover stored under the floor, as shown in these photographs.



• Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label will sit against the back of the rear seat.



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the Bootliner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion do not disturb during.

BASE

- Position the base snugly into place. Start behind the back of the rear seats
- The hook fasteners welded to the reverse face of the liner will attach directly to the floor carpet.





RECESS/POCKETS

• You will notice that the boot liner has been designed to accommodate the load cover stored under the false floor.

FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.

REAR PLUS VERSIONS

• YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS / THE HEADREST STRAPS BEFORE YOU RECLINE THE REAR SEAT UPPERS (Please refer to REAR PLUS options on website to see detailed photo')







SIDES

Please note the Boot Liner skims over these two recesses highlighted in red in the above photographs

SIDES

- Carefully position the side panels snugly into place.
- Front section of the sides: The hook fasteners welded to the reverse face of the liner will attach directly to the carpet.
- Use the self-adhesive loop fastener pads to attach the rest of the liner to the plastic area – indicated here in red




PLEASE NOTE

We have noted the carpet may fluff up if the boot liner is fitted/removed regularly. So we have also included some "Frequent use fastener patches" ref 113

Should you wish to uses these:

Attach one of the 14 ref: 113 (double sided fastener patches) under each of the hook fastener welds: location highlighted in black in this photo. If the 113 tab attaches directly to the carpet and the liner attaches to the tab. You can carefully peel the boot liner side away from the tab rather than the carpet.





Optional extras

Please note these photos are non-specific to your car.

TAILGATE COVER

• Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Lower the headrest before fitting the flap, so as not to impair the driver's rear view.
- Attach the Seat Flap to the fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats.
- The flap is then placed over the rear head rests and down the back of the passenger seats.
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts
- The Seat Flap can also be used in conjunction with the Rear Plus Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests

BUMPER FLAP

- Fit Boot Liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.
- Please note that the edges of the fabric are not bound so that any mud, dirt or water can run off.



