

FITTING INSTRUCTIONS hatchbaq.co.uk

JAGUAR F-PACE - 2016 - 2021

Our ref: H0624

FITTING KIT CONTENTS:

BOOTLINER

- 630mm cut length of 30mm wide self-adhesive loop fastener
- REAR DOOR COVER
- 15 x tabs self-adhesive loop fastener



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any Hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The Hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth.**

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.





STEP I. PREPARATIONS

PLEASE NOTE:

FLOOR RAILS. Remove the sliding D Ring Sections from the floor rails , the boot liner will sit over the rails. We do not accommodate this fixing functionality.

REAR SEAT POSITION. Ensure the rear seat uppers are set at the most upright position.



STEP 2. FITTING BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Start just in front of the locking mechanism (see arrow) and work forwards and outwards. Flatten the base so it fits snugly against the edges. (image A)
- Cut to length and shape, the 30mm wide selfadhesive loop fastener, so that it sits neatly into the 2 sections of the molded tailgate plate, either side of the locking mechanism. (image B) Fasten the rear end of the boot liner to this loop fastener.





STEP 3. FITTING THE FRONT

- - PLUS / SPLIT VERSION ONLY fasten the hook & loop fastener between the side panel and the seat panel. (image C)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (image D). Make sure to hold the front part of the base in position, as not to pull the boot liner too far up. Repeat the procedure with the left and right headrest.

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fastener + the headrest straps before you recline the rear seat uppers.

STEP 4. FITTING THE SIDES

• Attach the sides of the boot liner to the boot sides. The hook fasteners welded to the reverse face of the liner will attach directly to the carpet. (image E+F).







OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.
- The Seat Flap can also be used in conjunction with the **Rear Plus** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests (image 3)

STEP 5B. TAILGATE COVER



Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive hook fastener tabs will be stuck. (image 4) *Loosely fasten the 2 hook & loop fastener straps*

• Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP (IMAGE 5)


- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.











OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. BOOTLINER EXTENSION

The "Bootliner extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option.

- The Bootliner extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors

Please Note: The Seat Flap 5A, the Bumper Flap 5C & the Bootliner Extension 5D cannot be added at a later date.

STEP 5E. FREQUENT USE KIT

• If you frequently remove/install your boot liner from/to your vehicle, please note that the carpet will "fluff" up – we offer an alternative Frequent Use Fitting Kit. These tabs are placed between the boot liner and the boot carpet. (image 7 + 8)

The Frequent Use Kit is an accessory available to purchase from our on-line store





