

VAUXHALL ASTRA HATCH (5 DOOR) - 2015 to 2021

RAISED & LOW FLOOR

Our ref: Ho637-FRSD + FLOW

PACKAGING REQUIREMENTS.

BOOTLINER

- **2 x 390 mm** 30mm wide self-adhesive loop fastener
- **1x tab** self-adhesive loop fasteners

TAILGATE COVER

- **18 x tabs** self-adhesive loop fasteners



*RAISED VERSION
Rear Split version
prepared for a Seat Flap*

*LOW VERSION
Rear Split version
prepared for a Seat Flap &
Bootliner Extension*



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is **highly likely there will be a build-up of silicone**. Before applying any Hook & loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The Hook & loop fastener cannot be used once it has been in contact with silicone). We recommend "Intensive Tar Remover" made by AutoGlym and available from Halfords. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



STEP I. PREPERATIONS

- Remove the load cover. It may be replaced later.

Please note not all of the photographs are specific to your vehicle

STEP 2. FITTING BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fastener welded to the reverse face will fix directly to the carpet.



STEP 3. FITTING THE FRONT

- **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fastener between the side panels and seat panel. (image A)
- Starting with the middle headrest, pass the hook & loop fastener straps around both headrest posts. (image B). Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fastener + the headrest straps before you recline the rear seat uppers. (Please refer to REAR PLUS / SPLIT options on website to see detailed photo)


STEP 4. FITTING THE SIDES

- Fasten the hook fastener sewn / welded on the reverse face of the boot liner sides directly onto the carpet of the boot sides. (image C1 (Raised floor) +C2 (Low floor))



STEP 2. FITTING BACK

- Attach the 30 mm wide self-adhesive loop fastener strip onto the plastic panel located on both sides of the tailgate end of the boot. The hook fastener on the boot liner back panel fixes to this (Image D)
- Attach 1 self-adhesive loop fastener tab on the center of the inside face of the back plastic panel as indicated by the arrows in (image D)



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage over any exposed section of the seat backs and the headrests
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot Liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.



STEP 5B. TAILGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 4)



Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5C. BUMPER FLAP

- Fit Boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.

OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6 & 7)

- The Floor extension is designed to attach to a Rear Plus/Split version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It will offer no full protection to the rear doors
- Attach the floor extension to the main boot liner (Image 6)
- Fasten the two ties in the corner together (Orange arrows - Image 7)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 7)

The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date

STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit" (image 8+9)

The Frequent Use Kit is available to buy from our "on-line" Accessories Page – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

