

HYUNDAI SANTA-FE - 2012 on

5 SEATER & 7 SEATER (3RD ROW FOLDED)

OUR REF: H0662-SE5/SE7

PACKAGING REQUIREMENTS.

\square BOOTLINER (SE5 + SE7)

- 2x 550 mm 30mm wide selfadhesive loop fastener
- 2x 890 mm 30mm wide self-adhesive loop fastener
- 4x tabs self-adhesive loop fastener

7 SEATER ONLY

 2x 70mm 25mm wide sew-on loop fastener



7 seater - Split boot liner with bumper flap and seat flap

☐ TAILGATE COVER

• 26 x tabs self-adhesive loop



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fasteners sticks to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

- 1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
- 2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 selfadhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary)
- 3. Attach the fasteners and let them fully adhere over the next 24 hours for the best bond.



*The fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.






STEP I. PREPARATIONS

- Remove the load cover. It may be replaced later.
- Slide the 2nd row seats as far back to the tailgate as possible. (image A)
- Set the seats to a position as indicated by image A (90 mm gap between the load cover slot and the seat back)

7 SEATER ONLY

 Fold flat your 3rd row seats. These will not be usable when the boot liner is installed.



STEP 2. FITTING THE BASE

• Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. (image B)



STEP 3. FITTING THE FRONT

- PLUS / SPLIT VERSION ONLY fasten the hook & loop fasteners between the side panels and the seat panel. (image C)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (image D). Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

You MUST unfasten the HOOK & LOOP FASTENERS + the headrest straps before you recline the rear seat uppers. ('Please refer to REAR PLUS / SPLIT options on website to see detailed photo')





STEP 4. FITTING THE SIDES & BACK

7 SEATER ONLY

 Clip the 3rd row seatbelts in their corresponding clips on the side panel. (Image E)

ALL VERSIONS



Attach the 550mm long self adhesive loop fastener onto the side panel just below the load cover cassette slots and the 3rd row seats release latch as indicated in blue. (Image F)

• Fasten the hook fasteners sewn onto the top edge of the boot liner to the previously attached loop fastener.



Attach 2 self adhesive loop fastener tabs as highlighted in green, in line with the hook fasteners welded onto the top sides of the boot liner. (Image F)



Attach the 890mm long self adhesive loop fastener along the tailgate edge of the boot starting from the lock in the middle going along the plastic panel and up along the sides (as indicated in yellow image G).


- Snip the fastener strip in the corners to ease around the bend. Fasten the boot liner to it using the hook fasteners welded onto it.
- Repeat on the opposite side (image I)

7 SEATER ONLY

• Fasten the non-adhesive loop fastener tabs onto the hook fasteners sewn onto the boot liner in line with the seatbelt straps. This is to stop the hook fasteners scratching your seatbelts. (orange arrow image H)











OPTIONAL EXTRAS


Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the Rear Plus or Split Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Bootliner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

STEP 5B. TAILGATE COVER

Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive fastener tabs will be stuck. (image 4)



STEP 5C. BUMPER FLAP

- Fit Bootliner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the bootliner. (image 5)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.











OPTIONAL EXTRAS page 2

 ${\it Please note the following photos are non-specific to your vehicle}$

STEP 5D. FLOOR EXTENSION

The "Floor extension" offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 6)

- The Floor extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max width is 148cm (see photo on left).
- It will offer no protection to the rear doors



The Seat Flap 5A, The Bumper Flap 5C & The Floor Extension 5D cannot be added at a late date