

Toyota Aygo - 2014 on (inc. 2018 facelift)

our ref: H0751

PACKAGING REQUIREMENTS:

BOOT LINER

- **2 x 310 mm** 30mm wide self-adhesive loop fastener
- **6 x tabs** self-adhesive loop fastener

TAILGATE COVER

- *Not available*



Rear Plus with Seat Split boot liner



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and valeting.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.

STEP 2. FITTING THE BASE

- Place the boot liner into the car boot with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners welded to the reverse face fix directly to the carpet. *(image A)*



STEP 3. FITTING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and the seat panel. *(Orange arrows: image B)*
- The seat folding straps will sit behind the front panel *(Blue arrow: image B)*
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. *(image C)*. Make sure to hold the front part of the base in position as not to pull the boot liner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. *(Please refer to REAR PLUS / SPLIT options on website to see detailed photo)*

STEP 4. FITTING THE SIDES

- Just above the wheel arch section there are 4 hook fastener tabs on the reverse side of the Bootliner, these will attach directly to the carpet section of the boot side. *(image D)*
- Repeat on opposite side



STEP 4. CONTINUED

- Stick the self-adhesive loop fastener tabs onto the plastic (Image E)
- Fasten the boot liner to it using the hook fastener welded onto it. (Image F)
- Repeat on opposite side (Image G)



STEP 5. FITTING THE BACK

- Stick the 2 x 310 mm 30mm wide self-adhesive loop fastener onto the plastic panel located on both sides of the lock at the tailgate end of the boot. Snip the self-adhesive fastener strips to ease around the bend. Fasten the boot liner to it using the hook fastener sewn onto it. (Image H)



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 5A. SEAT FLAP

- The Seat flap is designed to protect the top of your rear seat giving additional protection from drooling dogs etc.
- The Seat Flap can also be used in conjunction with the **Rear Plus** or **Split** Option(s). With the rear seats in the folded position the Seat Flap extends the coverage forward. (image 3)
- Lower the headrests
- Attach the Seat Flap to the loop fastener strip that has been manufactured into the Boot liner just below the top of the rear seats. (image 1)
- The flap is then placed over the rear head rests and down the back of the passenger seats. (image 2)
- If the Seat Flap sits over large headrests and obstructs your rear view: carefully create openings in the flap to accommodate the headrest posts.

STEP 5C. BUMPER FLAP

- Fit boot liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the boot liner. (image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



OPTIONAL EXTRAS PAGE 2

Please note the following photos are non-specific to your vehicle

STEP 5D. FLOOR EXTENSION

The 'Floor extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 5 & 6)

- The Floor extension is designed to attach to a Rear Plus/Split version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It will offer no full protection to the rear doors
- Attach the floor extension to the main boot liner (Image 5)
- Fasten the two ties in the corner together (Orange arrows - Image 6)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 6)

The Seat Flap 5A, the Bumper Flap 5C & the Bootliner Extension 5D cannot be added at a late date.

STEP 5E. FREQUENT USE KIT

- If you frequently remove/fit your boot liner from/to your vehicle please note that the carpet will "fluff" up – we have an alternative "Frequent Use Fitting Kit" (image 7&8)

The Frequent Use Kit is available to buy from our "on-line" Accessories Page – simply add it to your order from the Factory Shop. These can also be ordered at a later date.

